

FITMENT GUIDE

BAT LOGICBasePlates



BasePlate pack contains:

- 2 x BasePlates (1 x left & 1 x right)
- ▶ 8 x 10mm Counter Sunk Screws (for most foot boards) B
- 8 x 12mm Counter Sunk Screws (for thicker foot boards) C
- ▶ 8 x Nuts (for the BasePlate) D









Equipment needed:

Philips Head Screw Driver and Spanner

Associated products:

ErgAdaptor

Enjoy all of the benefits of the QuickRelease System on the ergo. Click from boat to erg.



CustomPack

Customize your QuickRelease System to adjust for leg length discrepancy or added heel load.



ShoePlate Tops

The ShoePlate Tops attach to the Shoe and allow the shoe to click into the BasePlates which are affixed to the boat or ErgAdaptor. The ShoePlate Tops are therefore required for the system to function. Should your rowers not already have ShoePlate Tops for their rowing shoes, you will need to purchase these separately.



BASEPLATES WILL FIT ALMOST ALL BOAT FOOT STRETCHERS AS STANDARD.

If not, you foot stretcher screw pattern can be adjusted.





SAFETY WARNING: FISA approved heel restraints must be used while rowing. The QuickRelease System is not designed for walking. Walking on it may cause injury.





STEP 1 – ATTACH THE BASEPLATE

Remove the boat foot stretcher. Place 1 x nut (D) in one of the 4 hexagonal cavities on the top of the BasePlate. Screw the BasePlate to the foot stretcher using either screws (B) or (C) depending on the thickness of your foot stretcher. You will need to hold the nut as you screw the screw in (as shown). Repeat this for all nuts (D) and screws (B) or (C). You will need 4 screws only for each side (leaving you with 8 unused screws B or C).





STEERING FOOT ATTACHMENT

The QuickRelease System can be attached to a steering plate like a regular shoe. Simply fit the BasePlates to the steering plate/disc with the same instructions as above.







STEP 2 - ENGAGE YOUR SHOEPLATE TOPS INTO THE BASEPLATE

Line up the ShoePlate Top with the front tab of the BasePlate and place it on top. Slide the ShoePlate Top upwards to engage into the BasePlate, you should hear a click. Once engaged you should check the ShoePlate Top's tab is fully depressed by pushing down on it. This ensures a proper locked fitment. Clip on or tie on your FISA approved heel restraints. Repeat for each ShoePlate.







STEP 3 – TO RELEASE SHOEPLATE TOPS FROM BASEPLATES

Pull up on the release tab located at the toe of the ShoePlate Top to unlock it, slide the ShoePlate Top downwards to disengage from the BasePlate. You can now clip off or untie your heel restraints.





YOUR BOAT, YOUR SETTINGS, ANYTIME, ANYWHERE. BAT LOGIC.

